



ARLON

► How to Clean Etched Glass Film

Tools

- Microfiber cloth
- Water
- Dish washing soap
- Buckets to hold soapy water and rinse water

Step by step procedure

1. Mix mild dish washing soap i.e Dawn (1 to 2 drops per gallon of water)
2. Soak a clean microfiber cloth
3. Wipe graphics gently with a wet microfiber soapy cloth
4. Final wipe with a new wet microfiber cloth (water only)

Tip:

Make sure graphic is installed for 30 days prior to cleaning to ensure solid adhesion to glass.

November 2018